




**414CC MANUAL START ENGINE  
SERVICE KIT  
PLMHK2911501E1FIGP-BPSTE2**



43\*  
2\*  
\*Included with part# 1

1	Cylinder Head Assembly	SK4141050
2	Push Rod Tappet Kit	SK4141001
3	Valve Cover Assembly	SK4144500
4	Choke Lever, Carburetor	SK4142120
5	Piston Assembly	SK4141400
6	Connecting Rod Assembly	SK4141500
8	Flywheel Assembly, Manual Start	SK4141700
9	Flywheel Fan	SK4144000
10	Crankshaft	SK4141800
11	Air Filter Assembly of Paper	SK4142002
12	Filter Element, Panel Paper	SK4142012
13A	Muffler Assembly	SK4142100
14B	Fuel Tank Assembly	SK4147002
15	Fuel Petcock	SK4142220
16A	Plastic Fuel Cap (Click Style)	SK4148300
17	Carburetor Assembly	SK4142400
18	Ignition Coil Assembly	SK4142500
19	CDI Cox Assembly	SK4142750
20	On/Off Switch	SK2082600
21	Non-Removable Oil Plug	SK4143715

22	Black Oil Dipstick	SK4143711
24	Throttle Control Assembly	SK4142800
25	Governor Gear Assembly	SK4142900
26	Governor Link Assembly	SK4143000
27	Governor Arm Shaft Assembly	SK4143100
28B	Recoil Starter Assembly	SK4147001
29	Starter Cup	SK4143300
30B	Blower Housing Assembly	SK4147003
31	Crankcase Cover Assembly	SK4143600
32	Seal Kit	SK4143905
34	Spark Plug Boot	SK4143800
36	Engine Gasket Kit	SK4144300
37	Low Oil Sensor	SK4142700
39	Camshaft	SK4141600
41	Spark Plug	SK2911550
42	Top Shield	SK4141020
43	Rocker Arm Kit	SK4141100
44	Cylinder Assembly	SKSN4444
46	Fuel Hose Kit	SK4146000