






Model & Serial Number Label Location



Kawasaki Engine Labels: The above photos show typical placement of Kawasaki engine labels – on the block near the starter (top photo) and on the cooling shroud (bottom photo). Horizontal engines may have each label located just below the PTO on the crankcase cover.